

# Installation


Mounting instructions installation Precaution

Load connection

# Operation

Power ON/OFF

Operation and Display Panel



# LCD Display Icons

Main screen




Time setting screen



LCD brightless setting screen



Language setting screen



# LCD Display Icons

## Battery information screen




Defeat Password is 888888 and cannot be modify by User



## Battery parameter setting screen

Forbid to set parameter by LCD



## Battery serial number

Battery serial number and BMS serial number




## Battery fault code display

View and clear fault codes



## LCD shut down

Click this area once to turn off




## LCD Display Icons


### Battery power information




### Real-time power curve



### Total charging capacity curve



### Total discharge capacity curve



### LCD awaken

If the screen is closed, click any area of the screen to wake up the screen.

## Support inverter

Multiple protocols are built in the battery, supporting multiple inverters

